



Programming your Pendant (869MHz)

Green cancel key



Step 1. Press and hold the **green cancel key** until the unit beeps.

The red light will start flashing.

Release the green cancel key.

Step 2. Repeat Step 1

Step 3. Press and release the **red button** on your new pendant.

The unit will beep to confirm acceptance.

Step 4. Press and release the **green cancel key**.

The unit will beep.

The red light should stop flashing.

(If the red light continues to flash, press the green cancel key)

Step 5. Make a **test call using** the new programmed **pendant**.



If you have any problems please contact us at 1850 23 23 24